

Jemiclad™

How the professionals do it. Don't get left behind.

2. Apply spray adhesive to the substrate centred at the joints of the Jemiclad allow to dry and apply the Jemitape 1 tape.

3. Install sheets as above leaving the adhesive 25mm clear of the edge of the sheet.

4. Carefully cut through and remove half of the Jemitape 1 protective film and press the Jemiclad firmly onto the tape.

5. Install the remaining sheets leaving a 1.5mm gap between each sheet.

6. Clean all joints using anti-static wipes. This will prevent dust burning into the joints when welding.

7. Carry out a test weld on some off cuts or scrap material, to ensure the weld gun is at the correct temperature.

8. Weld the Jemiclad joints being extremely careful not to burn the sheets.

9. Allow the weld to cool and trim using a Mozart blade in a single pass where possible.



11.3 Trimmed Joints

1. Once the first panel of Jemiclad is installed cut down and tuck the back of the joint trim behind the sheet leaving a 1mm gap between the edge of the sheet and the clip channel of the back trim. Note, if a skirting transition trim is being installed the joint back needs to be cut short by 20mm to allow for this.
2. Following the installation of all the sheets and back trims, loosely install the front part of the joint trim by hand.
3. Cut down the front trim and final fit using a rubber mallet.



11.4 Trimmed Floor Transition

1. Once all the Jemiclad panels are installed install the cut tile trim by tucking it up behind the underside of the cladding.
2. Loose fit the cover trim bending along the way to form the internal and external angles.

11.5 Flash Cove Wall to Floor

1. Whilst installing the setting out the for the Jemiclad installation, set a low-level datum at the agreed cove height (usually 100 or 150mm 4 or 6") and mark it on the substrate.
2. Install your chosen cove former as per the manufacturer's instructions.
3. Install the 4" 1.5mm Jemitape from the Jemiclad Flash Cove Wall to Floor kit. This will be installed above the set skirting datum.
4. Install the 6" 2mm Jemitape below this line overlapping the cove former.
5. Install the Jemiclad panels as instructed above, peeling off the face film of the 4" tape and roll back the Jemiclad to the tape to ensure adhesion.
6. Carry out the installation of the vinyl flooring as the manufacturer's instruction, loose fitting the cove, leaving an additional 10mm to overrun the Jemiclad panels.
7. Using a metal cutting guide cut the vinyl flooring back to level with the underside of the Jemiclad. Ensure the vinyl is cut as straight and level as possible to give the best result.
8. Peel back the 6" Jemitape and adhere the vinyl cove.
9. Hot weld the Jemiclad and vinyl together using Jemiclad flexible PVC weld rod.
10. Trim back the weld with a Mozart knife.

